

## The PIPER Backup Tool



The  
**PIPER**  
Backup Tool



8 Piece Piper Backup Tool Kit

**A ONE MAN CREW CAN WORK LIKE TWO!!!!**

Now you don't need an operator to hold a back-up wrench.

**Works well in limited spaces!**

Just place the PIPER on the back side of the flange nut that's being tightened. A ball detent holds the PIPER onto the nut and flange. After the nut you are tightening is fully tightened, tap the Piper off of the nut and move to the next one.





**The PIPER Backup Tool**

<u>Part #</u>	<u>Nut Size</u>
SMP-78	7/8"
SMP-1116	1-1/16"
SMP-114	1-1/4"
SMP-1716	1-7/16"
SMP-158	1-5/8"
SMP-11316	1-13/16"
SMP-02	2"
SMP-2316	2-3/16"
SMP-238	2-3/8"
SMP-2916	2-9/16"
SMP-234	2-3/4"
SMP-21516	2-15/16"
SMP-318	3-1/8"
SMP-350	3-1/2"
SMP-378	3-7/8"
SMP-414	4-1/4"
SMP-458	4-5/8"
SMP-538	5-3/8"

**Piper Backup Tool Sets**

3 Piece set (7/8", 1-1/16", 1-1/4")
6 Piece set (7/8" to 1-13/16")
6 Piece set W/ Pelican Case
8 Piece set (7/8" to 2-3/16")
8 Piece set W/ Pelican Case

FOB: Bellaire, Texas

SMP Piper products are cast from 8620 steel that contains nickel, chrome and molybdenum as alloying elements. The tools have a Rockwell "C" level of 58-62.